








1	2
3	4



5	6
7	8



Unscrew the jackscrew after installation, Then adjust the position of the sliding door and tighten the jackscrew.